






# Fluid Inventory Control - TM Control

| MODEL   | DESCRIPTION  | COMPONENT TECHNICAL DATA   |
|---|--|--|
| <b>RECOMMENDED ACCESSORIES</b>  |  |  |
|              | <input type="checkbox"/> <b>3120-029</b> Tank alert strobe alarm   | Power: 24 V DC   |
|              | <input type="checkbox"/> <b>3120-033</b> Air solenoid valve  | Air Solenoid Provides for the remote shutdown of dispensing pumps from the fluid control console. Order one per controlled pump.<br><br>Pressure: 200 PSI (12 bar)<br>Connection: 3/8" NPT (F/F)<br>Power: 24 V DC |
| <b>TANK SENSORS</b>   |  |  |
| Tank sensors (switches provide low level/high level responses, depending on model)            |  |  |
| <br>3120-092 | <input type="checkbox"/> <b>3120-092</b> 1 Level Sensor, Switch, Single Probe, 5.6 ft. with 33 ft. cable         |  |
| <br>3120-093 | <input type="checkbox"/> <b>3120-093</b> 2 Level Sensor, Switch, Double Probe, 3 ft. & 5.5 ft. with 33 ft. cable |  |
| <br>3120-094 | <input type="checkbox"/> <b>3120-094</b> 1 Level Sensor, Switch, Flex Adjustable Single Probe, 16 ft. cable      |  |

