

Accessories & Supplies

Filters Regulators, and Lubricators (FRL)



1-piece Piggy Back Filter / Regulator

Best choice for pump air control. Filter prolongs wear life of pump, automatic drain removes moisture, regulator adjusts pump air supply pressure for best performance.



2-piece Piggy Back FRL Units

Air line filter and regulator with gauge allow for maximum air flow. Provides efficient water and particle removal and features an easy to read water level indicator.



3-piece FRL Units

Full air line control and conditioning for pump operation. Select from 1/4" through 3/4" and miniature sizes. Manual drain. (Automatic or mini).

F/R Minis for pressures up to 150 psi (10 bar) and flows of 15 SCFM
F/R standard for pressures up to 250 psi (17.24 bar) and flows of 25 SCFM

MODEL #	TECHNICAL DATA	DRAIN	MOUNTING BRACKET
3260-060	1/4" NPT(F) mini, poly bowl	Auto	3261-007
3260-033	1/4" NPT(F) mini, zinc bowl	Auto	3261-007
3260-065	1/4" NPT(F) mini, zinc bowl	Manual	3261-007
3260-066	1/4" NPT(F) mini, poly bowl	Manual	3261-007
3260-034	1/4" NPT(F)	Auto	3261-010
3260-035	3/8" NPT(F)	Auto	3261-010
3260-036	1/2" NPT(F)	Auto	3261-010
3260-037	3/4" NPT(F)	Auto	3261-011

MODEL #	TECHNICAL DATA	DRAIN	MOUNTING BRACKET
3260-059	1/4" NPT(F) mini, poly bowl	Auto	3261-007
3260-048	1/4" NPT(F) mini, zinc bowl	Auto	3261-007
3260-049	1/4" NPT(F)	Auto	3261-010 or 3261-008
3260-050	3/8" NPT(F)	Auto	3261-010 or 3261-008
3260-051	1/2" NPT(F)	Auto	3261-010 or 3261-008

MODEL #	TECHNICAL DATA	DRAIN	MOUNTING BRACKET
3260-053	1/4" NPT(F) mini	Auto	3261-007
3260-054	1/4" NPT(F)	Manual	3261-010 or 3261-008
3260-055	3/8" NPT(F)	Manual	3261-010 or 3261-008
3260-056	1/2" NPT(F)	Manual	3261-010 or 3261-008
3260-057	3/4" NPT(F)	Manual	3261-011 or 3261-009



Air Line Filter

Use air filters to remove moisture and particulate solids from air supply lines. Manual drain. (Automatic or mini).

MODEL #	TECHNICAL DATA	DRAIN	MOUNTING BRACKET
3260-038	1/4" NPT(F) mini	Auto	3261-008
3260-040	3/8" NPT(F)	Manual	3261-008
3260-041	1/2" NPT(F)	Manual	3261-008
3260-042	3/4" NPT(F)	Manual	3261-008
3260-061	1" NPT(F)	Manual	-



Air Regulators

Use air regulators to individually adjust supply pressure to air-operated pumps. Includes gauge.

MODEL #	TECHNICAL DATA	DRAIN	MOUNTING BRACKET
3260-028	1/4" NPT(F) mini	-	3261-007
3260-030	3/8" NPT(F)	-	3261-010
3260-031	1/2" NPT(F)	-	3261-010



Air Line Lubricators

Full air line control and conditioning for pump operation. Manual drain (Automatic or mini).

MODEL #	TECHNICAL DATA	DRAIN	MOUNTING BRACKET
3260-043	1/4" NPT(F) mini, poly bowl	-	N/A