## Fluid Inventory Control Nex-U-® U-vision & U-vision+



U-vision<sup>+</sup> adapts to any Balcrank oil control handle and transforms the handle into a hand-held display and keypad for access to the NEX-U.® system.





## **Features**

Use the U-vision to display reel, battery level, and delivery. Use U-vision $^+$  to dispense and to interact with the system.

- Modular design fits standard non-metered control handle
- Display dispensed data
- Display and input data

Non-metered control handle not included. Choose handle to fit your needs (pg. 108).

COMPONENT TECHNICAL DATA	
Function	Hand held display module
Requirements	Non-metered control handle, select on pg. 93
Power	U·vision+ and U·vision are powered with 4 "AA" 1.5 V alkaline batteries
Service Bulletin	
U·vision	SB 3803
U·vision +	SB 3809

MODELS AVAILABLE	
3110-112	U-vision hand-held display module
3110-113	Uvision <sup>+</sup> hand-held keypad and display module. (Control handle not included)

## **U**·vision

Hand-held display module to fit a Balcrank oil control handle. Includes a backlight display connected via Bluetooth® with a U·valve, U·meter+ or U·count module and it displays the following parameters:

- Hose reel (fluid outlet number and fluid dispensed type)
- Battery life and Bluetooth® signal strength
- Volume delivered and operation progress
- Solenoid valve open or closed

## U-vision+

U-vision<sup>+</sup> includes a six-button keypad and it can replace the U-dat keypad for data entry in the system as it allows the following operations:

- User access through PIN entry
- Scroll through existing open job orders to select the one corresponding to each operation or enter the job order number (alpha numeric)
- Enter the volume of fluid to be dispensed
- Confirm fluid type and transaction