

#### DESCRIPTION

## 7120-006 & 7120-007 Bung Kits:

When used properly these kits will seal the air vent passage above the bung adapter provided with the pump, preventing water from entering into product container.

7120-011 & 7120-012 Drum Cover/Bung Kits: When used properly these kits will seal below the drum cover, preventing product from spilling out and running down the side of the container.

# **INSTALLATION**

### 7120-006 & 7120-007 Bung Kits:

- 1. Remove pump from container and if necessary, unscrew footvalve to remove existing bung adapter from pump tube.
- 2. Locate the spring, metal washer, and rubber washer in the kit.
- 3. Slide the spring over the pump tube, then place the steel washer followed by the rubber washer over the pump tube.
- 4. Replace the bung adapter and footvalve on the pump tube, tighten, and place pump back on product container. (The weight of the pump will load the spring.) Tighten the bung adapter.

### 7120-011 & 7120-012 Drum Cover/Bung Kits:

- 1. Locate spacer and bolts provided in kits. Place the spacer on top of the cover, and the pump on top of the spacer. Bolt the pump and the spacer to the cover with the bolts provided.
- 2. Refer to installation instructions for kits 7120-006 & 7120-007 for completion of the bung seal kit for under the drum cover installation (see figure 1).

#### **BILL OF MATERIALS**

7120-006 & 7120-007 Bung Kits:

Items included are #3 spring, #4 washer, and #5 seal.

7120-011 & 7120-012 Drum Cover/Bung Kits:

Items included are #1 spacer & bolts, #2 cover, #3 spring, #4 washer, and #5 seal. Figure 1 **BUNG SEAL KITS** 

Model: 7120-006

7120-007

7120-012

